

## PORTABLE GAMING SPEAKER ENCEINTE GAMING PORTABLE TRAGBARER GAMING-LAUTSPRECHER ポータブルゲーミングスピーカー

# TQ-PG300

### Operating instructions Mode d'emploi Bedienungsanleitung 取扱説明書

- English
- Français
- Deutsch
- 日本語



© 2024 Pioneer Corporation. All rights reserved.  
© 2024 Pioneer Corporation. Tous droits réservés.  
© 2024 パイオニア株式会社 禁無断転載

#### PIONEER EUROPE NV (authorized representative)

Haven 1087, Keetberglaan 1, B-9120 Melsele, Belgium/Belgique  
TEL: +32 (0)3 570 05 11  
Salamanca, Wellington Street, Slough, SL1 1YP, UK  
TEL: +44 (0)208 836 3500  
http://www.pioneer-car.eu

#### PIONEER CORPORATION

28-8, Honkomagome 2-chome, Bunkyo-ku, Tokyo 113-0021, Japan/Japon  
パイオニア株式会社  
〒113-0021 東京都文京区本駒込2-28-8 文京グリーンコート  
http://global.pioneer

<TRD1526-D>

### English

#### Before you start

Thank you for purchasing this product. Be sure to read these “Operating instructions” thoroughly and use the product correctly. In particular, be sure to read the “Safety precautions” before use. When allowing young children to use this product, a parent or guardian should read these instructions thoroughly and explain them to the child.



If you want to dispose this product, do not mix it with general household waste. There is a separate collection system for used electronic products in accordance with legislation that requires proper treatment, recovery and recycling.

Private households in the member states of the EU, in Switzerland and Norway may return their used electronic products free of charge to designated collection facilities or to a retailer (if you purchase a similar new one).

For countries not mentioned above, please contact your local authorities for the correct method of disposal.

By doing so you will ensure that you disposed product undergoes the necessary treatment, recovery and recycling and thus prevent potential negative effects on the environment and human health.

#### Listening Safety

Over time your hearing “comfort level” adapts to higher volumes so that what sounds “normal” can actually be loud and harmful to your hearing. Guard against this by setting your equipment at a safe level BEFORE your hearing adapts.

- Set your volume control at a low setting, then slowly increase the volume until you can hear it comfortably and clearly, without distortion. Once you have established a comfortable sound level, leave it there.
- Do not turn up the volume so high that you can't hear what's around you.
- Use caution or temporarily discontinue use in potentially hazardous situations.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FEDERAL COMMUNICATIONS COMMISSION SUPPLIER'S  
DECLARATION OF CONFORMITY  
Product Name: PORTABLE GAMING SPEAKER  
Model Number: TQ-PG300

Responsible Party Name: PIONEER ELECTRONICS (USA) INC.  
SERVICE SUPPORT DIVISION

Address: 970 West 190th Street Suite 360, Torrance, CA 90502 U.S.A.  
Tel: 800-421-1404  
URL: https://usa.pioneer

Information to user

Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.

#### Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. There limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Safety precautions

##### ⚠ WARNING

- Do not let the product come into contact with water or moisture. This may cause a fire, electric shock, or malfunction. In particular, be careful when using the product on a rainy day, when it is snowing, at the beach, or near water.
- Do not use the product in a bathroom or shower room. This may cause a fire, electric shock, or malfunction.
- Do not plug or unplug the supplied charging cable into/from a gaming device with wet hands. This may cause an electric shock.
- Keep small parts such as L-shaped adapters and rubber parts that have peeled off from the product out of the reach of infants and toddlers, and ensure that they do not put such parts in their mouths or swallow these parts. In the event that they have swallowed such parts, contact a doctor immediately.

##### ⚠ CAUTION

- Ensure that the opening of the holding guide is not blocked, and that foreign objects and dirt do not enter the USB Type-C® input terminal. This may cause a functional or operational malfunction.
- Do not use the product if it is damaged or deformed, and do not touch the damaged or deformed parts, or attempt to fix it yourself. This may cause injury or malfunction.
- Do not use the product in locations where heat tends to accumulate or locations that reach high temperatures. Keep the product away from devices that generate heat, such as stoves and heaters, locations exposed to direct sunlight, and the inside of cars under the hot sun.
- Do not use the product for extended periods of time. Failure to follow the caution may cause the product hot resulting in low-temperature burns.
- Be careful not to let your fingers get caught in the holding guide, stand, or moving parts of the product. This may cause injury.
- Do not drop the product. Failure to follow the caution may cause parts to break or come off, resulting in injury.
- Do not insert foreign objects such as metal pieces into the USB Type-C® input terminal. This may cause heat to be generated, resulting in burns.
- Ensure that dust and dirt do not adhere to the surface of the product. This could prevent the gaming device from dissipating heat.

#### Accessories

- L-shaped adapter x 1
- Operating instructions x 2 sheets

#### Part names/Connection (→ Attachment)

#### Usage

##### Widening the sound field

- Turn on the **WIDE (audio switching) switch**.  
Sound will be heard from a wider area.

##### Raising the volume

- Turning the **HI VOL (gain switching) switch to High**.  
If you feel that the volume is not loud enough despite the volume on the gaming device being set to the highest level, turn this switch to High to increase the perceived volume. If the sound cuts out or makes abnormal noises, turn this switch to Normal.  
Certain settings on gaming devices, such as the “Lower Max Headphone Volume” option, may prevent the product volume from increasing. For details, check the user manual of your gaming device.

##### Placing the product with a connected gaming device on a table

- **Slowly open the stand until it is locked in place**.  
The product can be used with it placed on a table or similar. Close the stand when not in use.

##### Charging the gaming device

- **With the gaming device mounted onto this product, connect the charging cable supplied with the gaming device to the USB Type-C® charging port of this product**.  
Charging may not take place if a cable other than the charging cable supplied with the gaming device is used.  
Attach the L-shaped adapter supplied with this product to the charging cable supplied with your gaming device, and then connect it to the USB Type-C® charging port of this product to perform charging without bending the charging cable.

#### Specifications

Dimensions..... 80 mm (W) x 130 mm (H) x 35 mm (D)  
Weight .....0.13 kg

- This product uses CRI SOLIDAS developed by CRI Middleware Co, Ltd.

- USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.
- The serial number is the 10-digit alphanumeric number listed on the back of the product (back of the stand). Example: “DADS000001”
- The above specifications and design are subject to change without notice for improvements.

#### Warranty

The product warranty period is one year.

### Français

#### Avant de commencer

Merci d'avoir acheté ce produit. Lisez attentivement ce « Mode d'emploi » et utilisez le produit correctement. Veillez notamment à lire les « Consignes de sécurité » avant toute utilisation. Si vous laissez un jeune enfant utiliser ce produit, un parent ou un adulte responsable doit lire attentivement ces instructions et les expliquer à l'enfant.



Si vous souhaitez vous débarrasser de cet appareil, ne le mettez pas à la poubelle avec vos ordures ménagères. Il existe un système de collecte séparé pour les appareils électroniques usagés, qui doivent être récupérés, traités et recyclés conformément à la législation.

Les habitants des états membres de l'UE, de Suisse et de Norvège peuvent retourner gratuitement leurs appareils électroniques usagés aux centres de collecte agréés ou à un détaillant (si vous rachetez un appareil similaire neuf). Dans les pays qui ne sont pas mentionnés ci-dessus, veuillez contacter les autorités locales pour savoir comment vous pouvez vous débarrasser de vos appareils. Vous garantirez ainsi que les appareils dont vous vous débarrassez sont correctement récupérés, traités et recyclés et préviendrez de cette façon les impacts néfastes possibles sur l'environnement et la santé humaine.

#### Sécurité auditive

Au fil du temps, votre « niveau de confort » auditif s'adapte à des volumes sonores plus élevés, de sorte que ce qui peut sembler « normal » peut, en fait, être fort et nocif pour votre audition. Protégez-vous contre ceci en réglant votre équipement à un niveau adéquat AVANT que votre audition ne s'adapte.

- Réglez le volume sur un niveau faible, puis augmentez lentement le volume jusqu'à ce que vous puissiez l'entendre confortablement, clairement et sans distorsion. Une fois que vous avez établi un niveau sonore confortable,

laissez-le à ce niveau.

- N'augmentez pas le volume au point de ne plus pouvoir entendre ce qui se passe autour de vous.
- Soyez prudent ou arrêtez temporairement l'utilisation lors de situations potentiellement dangereuses.

#### Consignes de sécurité

##### ⚠ AVERTISSEMENT

- Ne laissez pas le produit en contact avec de l'eau ou de l'humidité. Cela peut provoquer un incendie, un choc électrique ou un dysfonctionnement. Soyez particulièrement vigilant si vous utilisez le produit alors qu'il pleut, qu'il neige, à la plage ou à proximité d'eau.
- N'utilisez pas le produit dans une salle de bains ou d'eau. Cela peut provoquer un incendie, un choc électrique ou un dysfonctionnement.
- Ne branchez ou débranchez pas le câble de charge fourni au/du périphérique de jeu si vos mains sont mouillées. Cela peut provoquer un choc électrique.
- Tenez les petits éléments, comme les adaptateurs en L et les éléments en caoutchouc tombés du produit, hors de portée des nourrissons et jeunes enfants, et veillez à ce qu'ils ne portent pas ces éléments à leur bouche ni ne les avalent. En cas d'ingestion de ces éléments, contactez immédiatement un médecin.

##### ⚠ ATTENTION

- Veillez à ce que l'ouverture du guide de maintien ne soit pas obstruée et à ce que les objets étrangers et la saleté ne puissent pas pénétrer dans la prise d'entrée USB Type-C®. Cela pourrait entraîner une panne fonctionnelle ou opérationnelle.
- N'utilisez pas le produit s'il est endommagé ou déformé, ne touchez pas les parties endommagées ou déformées et ne tentez pas de les réparer vous-même. Cela pourrait entraîner des blessures ou un dysfonctionnement.
- N'utilisez pas le produit dans des lieux où tend à s'accumuler de la chaleur ou atteignant des températures élevées. Tenez le produit éloigné des appareils générant de la chaleur, comme les poêles et radiateurs, et des lieux exposés à la lumière directe du soleil, et ne le laissez pas dans un véhicule garé en plein soleil.
- N'utilisez pas le produit pendant de longues périodes. Le non-respect de cette consigne peut faire chauffer le produit et entraîner des brûlures à basse température.
- Veillez à ne pas coincer vos doigts dans le guide de maintien, le support ou les éléments mobiles du produit. Vous risquez de vous blesser.
- Ne faites pas tomber le produit. Le non-respect de cette consigne peut causer la rupture ou le détachement d'éléments et entraîner des blessures.
- N'insérez pas de corps étrangers, comme des pièces métalliques, dans la prise d'entrée USB Type-C®. Cela pourrait générer de la chaleur et provoquer des brûlures.
- Veillez à ce que la poussière et la saleté n'adhèrent pas à la surface du produit. Dans le cas contraire, le film de saleté pourrait empêcher le périphérique de jeu de dissiper la chaleur.

#### Accessoires

- Adaptateur en L x 1
- Mode d'emploi x 2 feuilles

#### Noms des éléments/Connexion (→ Document joint)

#### Utilisation

##### Élargir le champ sonore

- **Activez l'interrupteur WIDE (commutation de l'audio)**.  
Le son est émis depuis une zone plus large.

##### Augmenter le volume

- **Réglage de l'interrupteur HI VOL (commutation du gain) sur High**.  
Si vous estimez que le volume n'est pas suffisamment fort bien que le volume du périphérique de jeu soit réglé au niveau maximal, réglez cet interrupteur sur High pour augmenter le volume perçu. Si le son se coupe ou émet des bruits anormaux, réglez cet interrupteur sur Normal. Certains réglages effectués sur le périphérique de jeu, comme l'option « Réduire le volume max. du casque », peuvent empêcher l'augmentation du volume du produit. Pour obtenir des détails, consultez le mode d'emploi de votre périphérique de jeu.

##### Placer sur une table le produit connecté à un périphérique de jeu

- **Ouvrez lentement le support jusqu'à ce qu'il se verrouille en place**.  
Le produit peut être utilisé posé sur une table ou dans une position similaire. Fermez le support si vous ne l'utilisez pas.

